

ASSEMBLY INSTRUCTION

MODEL : HM 352.02 DESC : 4 DOOR TOP CLOSET WITH WARDROBE

HARDWARE	SOFT DRY CLOTH	CHEMICAL		HEAT	KEEP DRY	DO NOT USE KNIFE	HANDLE WITH CARE		

A	WOOD BOLL Ø X 20	12	H	12MM NAIL 56	24
B	HANDLE 106 (PVC)	4	G	12MM CB SCREW M4X20MM	32
C	25MM CB SCREW M4X25MM	16	F	HINGES 20	4 SETS
D	38MM CB SCREW M4X38MM	12	E	HINGES 56	4 SETS

PART LIST

STEP 1

STEP 2

STEP 3

STEP 4

STEP 5

STEP 6

COMPLETED

COMPLETED

STEP 1

COMPLETED