

ASSEMBLY INSTRUCTION

MODEL : HM 2231.01

DESCRIPTION: CANDOR

SOFT DRY CLOTH	CHEMICAL	HEAT	KEEP DRY	HANDLE WITH CARE	DO NOT USE KNIFE	

HARDWARE		PART LIST	
A	WOOD PANEL 8 X 25 1X10	1X36	1X12
B	CR SCREW M3 X 8 (8MM) 1X36	1X36	1X12
C	CR SCREW M3 X 8 (8MM) 1X12	1X36	1X12
D	MINIFIX CAP 1X6	1X36	1X12
E	NAIL 5/8 1X36	1X36	1X12
F	L KEY 1X1	1X36	1X12
G	3.5KG MAGNET (1 HOLE) 2 SETS	1X36	1X12
H	CR SCREW M3 X 20MM 1X2	1X36	1X12
I	MAS L4 1X1	1X36	1X12
J	MINIFIX 6X4 X 12 6 SETS	1X36	1X12
K	HANDLE SCREW (METAL) 1X3	1X36	1X12
L	HANDLE SCREW M3 X 10MM 1X2	1X36	1X12
M	HANDLE SCREW M3 X 10MM 1X1	1X36	1X12
N	METAL SHELF SUPPORT 1X8	1X36	1X12
O	500 PVC LEG 1X4	1X36	1X12
P	P1 P2 1 SET	1X36	1X12
	DRAWER SLIDE 1/2" 1 SET	1X36	1X12

STEP 1

STEP 2

STEP 3

STEP 4

STEP 5

STEP 6

STEP 7

STEP 8

STEP 9

STEP 10

STEP 11

STEP 12

STEP 13

STEP 14

STEP 15

STEP 16

STEP 17

COMPLETED