

ASSEMBLY INSTRUCTION

MODEL : HM 2210 DESC : SHOE CABINET WITH 4 DOORS

SOFT DRY CLOTH	CHEMICAL	HEAT	KEEP DRY	HANDLE WITH CARE	DO NOT USE KNIFE	

HARDWARE		PART LIST	
A	WOOD DOVEL 8 X 25 1X4	B	16MM CB SCREW MAX20MM 1X24
C	38MM CB SCREW MAX20MM 1X8	D	NAIL 08 1X25 1X25
E	PVC SHELF SUPPORT SPRING 1X16	F	DOOR SUPPORT SPRING 1X2
G	1.5KG MAGNET (1 HOLE) 4 SETS	G1	1.5KG MAGNET (1 HOLE)
G2	12MM CS SCREW MAX20MM 4 SETS	G3	12MM CS SCREW MAX20MM 4 SETS
H	MAS L4 1X1	H1	MAS L4 1X1
H2	MAS R4 1X1	H3	MAS R4 1X1
I	MAS L2 1X1	I1	MAS L2 1X1
I2	MAS R2 1X1	I3	MAS R2 1X1
J	ROUND PLASTIC LEG (PVC) 1X4	K	MINIFX 364-546 4 SETS
K1		K2	
L	L-KEY 1X1	M	CLICKFIT CAP 1X4
N	HANDLE 522 (METAL) 1X4	O	HANDLE SCREW MAX20MM 1X4

STEP 1

STEP 2

STEP 3

STEP 4

STEP 5

STEP 6

STEP 7

STEP 8

STEP 9

STEP 10

STEP 11

STEP 12

COMPLETED