

# ASSEMBLY INSTRUCTION

MODEL : HM 2208 DESC : SHOE CABINET WITH 2 DOORS

	SOFT/DRY CLOTH	CHEMICAL	HEAT	KEEP DRY	HANDLE WITH CARE	DO NOT USE KNIFE

HARDWARE		PART LIST	
<b>A</b>	16MM CB SCREW M3.5X10MM MAX3MM	<b>M</b>	22MM HANDLE SCREW M4X20MM 1X2
<b>B</b>	38MM CB SCREW M3.5X10MM MAX3MM	<b>L</b>	HANDLE SOZZ (METAL) 1X2
<b>C</b>	NAIL 3/8 1X16	<b>K</b>	QUICKFIT CAP 1X4
<b>D1</b>	3.5 KG MAGNET (1 HOLE)	<b>J</b>	L-KEY 1X1
<b>D2</b>	2 SETS	<b>I</b>	MINIFX 684-5548 4 SETS
<b>D3</b>	CB SCREW M3.5X10MM MAX3MM	<b>H</b>	ROUND PLASTIC LEG (PPG) 1X4
<b>E</b>	PVC SUPPORT 1X8	<b>G2</b>	MAS L4 1X1
<b>F</b>	DOOR SPRING 1X2	<b>G1</b>	MAS R4 1X1
<b>G</b>	1X2	<b>G2</b>	1X1
<b>H</b>	1X4	<b>F</b>	1X2
<b>I</b>	4 SETS	<b>E</b>	1X8
<b>J</b>	1X1	<b>D3</b>	1X2
<b>K</b>	1X4	<b>D2</b>	2 SETS
<b>L</b>	1X2	<b>D1</b>	2 SETS
<b>M</b>	1X2	<b>C</b>	1X16

**STEP 1**

**STEP 2**

**STEP 3**

**STEP 4**

**STEP 5**

**STEP 6**

**STEP 7**

**STEP 8**

**STEP 9**

**COMPLETED**

**STEP 10**

**STEP 11**

**STEP 12**