

ASSEMBLY INSTRUCTION

DESC : SHOE CABINET WITH 3 DOORS

MODEL : HM 2211

SOFT DRY CLOTH	CHEMICAL	HEAT	KEEP DRY	HANDLE WITH CARE	DO NOT USE KNIFE	

HARDWARE		STEP 1		STEP 2		STEP 3		STEP 4	
A	16MM CS SCREW 1X26	D1	3.5 AC MAGNET (1 HOLE) 3 SETS	E	PVC CLIP SUPPORT 1X16	F	DOOR HINGE SPRING 1X3	G	G1 G2
B	35MM CS SCREW 1X6	D2	DOOR HINGE SPRING 1X3	F	DOOR HINGE SPRING 1X3	G	G1 G2	H	ROUND PLASTIC LEG (PVC) 1X5
C	NAIL 30 1X23	D3	CS SCREW 1X26	G	DOOR HINGE SPRING 1X3	H	ROUND PLASTIC LEG (PVC) 1X5	I	MINI KEY 304-0548 6 SETS
D	7	D4	DOOR HINGE SPRING 1X3	H	ROUND PLASTIC LEG (PVC) 1X5	I	MINI KEY 304-0548 6 SETS	J	L-KEY 1X1
E	10	D5	DOOR HINGE SPRING 1X3	I	MINI KEY 304-0548 6 SETS	J	L-KEY 1X1	K	DRILL BIT 1X6
F	11	D6	DOOR HINGE SPRING 1X3	J	L-KEY 1X1	K	DRILL BIT 1X6	L	HANDLE SCREW (METAL) 1X3
G	12	D7	DOOR HINGE SPRING 1X3	K	DRILL BIT 1X6	L	HANDLE SCREW (METAL) 1X3	M	HANDLE SCREW (METAL) 1X3
H	13	D8	DOOR HINGE SPRING 1X3	L	HANDLE SCREW (METAL) 1X3	M	HANDLE SCREW (METAL) 1X3		
I	14	D9	DOOR HINGE SPRING 1X3	M	HANDLE SCREW (METAL) 1X3				
J	15	D10	DOOR HINGE SPRING 1X3						
K	16	D11	DOOR HINGE SPRING 1X3						
L	17	D12	DOOR HINGE SPRING 1X3						
M	18	D13	DOOR HINGE SPRING 1X3						

PART LIST

STEP 1

STEP 2

STEP 3

STEP 4

STEP 5

STEP 6

STEP 7

STEP 8

STEP 9

STEP 10

STEP 11

STEP 12

COMPLETED