## ASSEMBLY INSTRUCTION MODEL CODE: 248-000009



HARDWARE ITEM			QTY
A2		Screw m3.5 x 14mm	8
A17		Crosshead Screw m6.3 x 40mm	24
L1	$\bigcirc$	Leg Pin	4
N1		Allen Key	1
N3		Nail	50 (+-3)
R1		L Bracket	2

## CAUTION

MATERIAL USE LAMINATED PARTICLE BOARD, TO CLEAN USE SOFT, DRY CLOTH. DO NOT USE DETERGENT OR CHEMICAL AVOID CONTACT WITH WATER AND DIRECT SUNLIGHT. TO BE ASSEMBLED ON A SOFT, DRY, CLEAN SMOOTH SURFACE.

USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.



STEP 1First, join panel no. 1, 2 & 3 together by using<br/>Crosshead Screw m6.3 x 40mm (A17). Use Allen<br/>Key (N1) to tighten the Crosshead Screw m6.3 x<br/>40mm (A17).STEP 2



STEP 3Attach the back panel no. 4 to the unit and secure<br/>it by Nail (N3). Assemble L Bracket (R1) by using<br/>screw m3.5 x 14mm (A2). Attach the Leg Pin (L1)<br/>at the bottom of both panel no.1.

(N3) (N3) (N3) (N3) (N3) (N3) (N3) (L1) 4 1 4 (N3) 1 (N3) A2 (L1) 8 8 (Rľ) 2 R1 (L1 3 (A2) 📽 🧬 2 pcs (L1



Join panel no. 1 to the unit by using Crosshead

Screw m6.3 x 40mm (A17). Use Allen Key (N1) to

tighten the Crosshead Screw m6.3 x 40mm (A17).

(A17

(A17

(N1)

(A17

harit

(A17

2

1

A17

(A17

2

2

1

3

3

COMPLETE

Stand

up

2

2