










## ΟΔΗΓΙΕΣ ΑΡΜΟΛΟΓΗΣΗΣ JASMIN ΣΥΝΘΕΣΗ




|    |      |      |    |   |       | ΠΑΚΕΤΟ |
|----|------|------|----|---|-------|--------|
| 1  | 1700 | 415  | 16 | 1 | J-201 | 1/3    |
| 2  | 1184 | 397  | 16 | 1 | J-202 | 1/3    |
| 3  | 518  | 397  | 16 | 1 | J-107 | 1/3    |
| 4  | 483  | 396  | 16 | 1 | J-306 | 1/3    |
| 5  | 202  | 397  | 16 | 1 | J-111 | 1/3    |
| 6  | 1004 | 415  | 16 | 1 | J-203 | 1/3    |
| 7  | 780  | 250  | 16 | 1 | J-305 | 1/3    |
| 8  | 300  | 397  | 16 | 1 | J-109 | 1/3    |
| 9  | 518  | 413  | 16 | 1 | J-108 | 1/3    |
| 10 | 1368 | 696  | 16 | 1 | J-106 | 2/3    |
| 11 | 463  | 1004 | 16 | 1 | J-101 | 2/3    |
| 12 | 270  | 250  | 16 | 1 | J-110 | 2/3    |
| 13 | 270  | 250  | 16 | 1 | J-103 | 2/3    |
| 14 | 578  | 250  | 16 | 2 | J-302 | 2/3    |
| 15 | 312  | 1197 | 16 | 1 | J-001 | 2/3    |
| 16 | 578  | 250  | 16 | 2 | J-307 | 2/3    |
| 17 | 636  | 250  | 16 | 1 | J-301 | 2/3    |
| 18 | 921  | 250  | 16 | 1 | J-304 | 2/3    |
| 19 | 270  | 250  | 16 | 2 | J-102 | 2/3    |
| 20 | 200  | 250  | 16 | 2 | J-104 | 2/3    |
| 21 | 326  | 1193 | 3  | 1 | J-601 | 2/3    |




# 1




# 2




# 3




# 4




5




7







6




8







# 13



# 15



# 14



# 16

