









Installation manual/Aufbauanleitung

TV STAND 2D



















MÖBEL 3677 LOWBOARD TV 2D NEPTUNE W/SE




Code/Kode	Dimensions/Ausmaß			Anzahl	Package/Paket
001	1380	400	16	1	1/1
002	544	320	16	1	1/1
003	395	220	45	1	1/1
004	296	414	16	1	1/1
005	304	380	16	1	1/1
006	304	380	16	1	1/1
009	1380	400	16	1	1/1
010	322	1364	3	1	1/1
011	304	340	16	1	1/1
012	304	340	16	1	1/1
accessories/zubehör				2	1/1




Accessories/Zubehör:


<p>x4 a144</p> 	<p>x4 b119</p> 	<p>x2 c43</p> 	<p>x4 d18</p> 
<p>x13 e1</p> <p>Ø7x50mm</p> 	<p>x13 s1</p> 	<p>x20 f1</p> <p>Ø8x30mm</p> 	<p>x1 f3</p> 
<p>x4 l2</p> 	<p>x1 n14</p> 	<p>x1 p17</p> 	<p>x14 p25</p> 
<p>x4 p38</p> 	<p>x8 r1</p> 	<p>x8 s2</p> 	<p>x8 r16</p> 
<p>x1 z1</p> 	<p>x4 k88</p> 	<p>x1 k87</p> 	




1




2




3




4




5




6




7




8



9



10



11

