







Installation manual

RIKO: Chest 2D4S



Element symbol	Dimensions	Code	Package			
1	1450	452	16	1	P-204	1/1
2	1416	427	16	1	P-307	1/1
3	884	450	16	1	P-107	1/1
4	884	450	16	1	P-108	1/1
5	808	427	16	1	P-109	1/1
6	808	427	16	1	P-110	1/1
7	464	427	16	2	P-308	1/1
8	400	150	16	4	P-505	1/1
9	400	150	16	4	P-506	1/1
10	399	150	16	4	P-507	1/1
11	399	150	16	4	P-508	1/1
12	203	468	16	3	P-005	2/2
13	60	1416	16	2	P-404	1/1
14	821	469	16	2	P-004	2/2
15	203	468	16	1	P-005	2/2
16	833	472	3	1	P-606	2/2
17	833	481	3	2	P-607	2/2
18	413	382	3	4	P-608	2/2


32x	s1	6x	ps2
4x	a143	4x	b119
1x	50r	8x	d1

4x	p42	32x	e1
6x	k1	42x	f1
20x	l1	20x	r1


8x	p21	8x	p11
4x	L	1x	z1
50x	p11	50x	p25




1




3




2




4




5




6




7




8




a=b



9



11



10

