


Instruction

- 1.Lamp used: LED Max.3.5W 220-240V AC 50Hz
2. Keep the luminaires away from dank or hot circumstance.
3. Please keep your hand dry when you touch switch.
4. Don't change any part of the luminaires by yourself.
5. Don't play it by children.
- 6.If the exemal flexible cable or cord of this lminaires is damaged,it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

Touch



Charging Description

