








197-000177



Instruction Manual





A01 16x *14 mm	A02 16x *5x45 mm	A03 16x *8x30 mm	A04 16x
A10 32x *4x20 mm	A11 20x *4x25 mm	A12 4x 	A13 4x
A15 4x 	A13 5x 	A14 4x 	A28 25x
A40 12x 			




Important information
Read carefully.
Keep this information for further reference.

GB WARNING


Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.

Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer.


7.




1.




2.




3.



4.



5.



6.

