








197-000182



Instruction Manual





A01 *14 mm 14x	A02 *5x45 mm 14x	A03 *8x30 mm 16x	A04 14x
A10 *3.5x18 mm 14x	A13 8x	A14 4x	A15 8x
A16 4x	A17 *3.5x50 mm 3x	A18 *4x20 mm 32x	A19 4x
A20 4x	A21 4x	A22 4x	A23 8x





Important information
Read carefully.
Keep this information for further reference.

GB WARNING


Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.

Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer.


14.





1.






2.





3.




4.




13.





11.






12.




5.




6.






7.



8.



9.



10.

